QUICK REFERENCE GUIDE

MITEL

5312 IP Phone



NOTE: For more information about using other features, or about programming Personal Keys on your 5312 IP Phone, refer to the *5312/5324 IP Phone User Guide* located at www.mitel.com, or contact your Administrator.

Make a Call

- 8 Lift the handset, or
- 3 Press 🕼 .
- **5** Dial the desired number, or
- **6** Press a **Speed Call** key, or
- 4 Press ¹²³, or
- **5** Dial the prefix for external calls (e.g. 9) and the number.

Answer a Call

- 8 Lift the handset, or
- **3** Press **()** and begin speaking.

End a Call

- 4 Press , or
- 8 Replace the handset.

Place a Call on Hold

- Press Area . The line key flashes.
 8 Replace the handset if necessary.
- Retrieve a Call from Hold
- 8 Lift the handset, or

3 Press 📢).

6 Press the flashing line key.

Retrieve a Message

Press I I flashes when a message is waiting. Follow the voice mail prompts to retrieve your message.

Transfer a Call

- 4 Press 🖍 🔊 .
- **5** Dial the number. Wait for an answer.
- 8 Hang up, or announce the transfer and then hang up.

Conference Calls

- 4 Press n.
- **5** Dial the number. Wait for an answer.
- 4 Press 🖍 🔊 .

Program a Speed Call



Adjust Volume Levels

Adjust ringer volume while the phone is ringing. Adjust speaker volume while using the handset or speaker.

3 Press **(A)** repeatedly to raise the volume,

or repeatedly to lower the volume.

S Press Z to mute your microphone. See the 5312/5324 IP Phone User Guide for details.

M Mitel (design) is a registered trademark of Mitel Networks Corporation. © 2008, Mitel Networks Corporation. All other products and services are the trademarks of their respective holders. All rights reserved.